## ClinicSearch

### **Clinical Trials and Case Studies**

Rehan Haider \*

Open Access Review Article

# Eye Drops Leakage and Discoloration Market Complaints Investigation and Packaging Solution

#### **Anupam Chanda**

Head Packaging and Polymer Science Technologist (PG). Principal Consultant: Bioxytran Inc, MA, Boston, USA.

\*Correspondence Author: Anupam Chanda. Packaging and Polymer Science Technologist (PG). Principal Consultant: Bioxytran Inc, MA, Boston, USA.

Received Date: June 09, 2025 | Accepted Date: June 18, 2025 | Published Date: June 23, 2025

**Citation:** Anupam Chanda, (2025), Eye Drops leakage and Discoloration Market complaints investigation and Packaging Solution, *Clinical Trials and Case Studies*, 4(3); **DOI:**10.31579/2835-835X/115

**Copyright:** © 2025, Anupam Chanda. This is an open-access article distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited.

#### **Abstract:**

Leakage and discoloration of Eye drops are very frequent and market complaint in USA market. In this Article I will try to explain these issues in three different steps like: Eye drop bottle and Cap design problems, Polymer compatibility problems with product and Leachable issues from Bottle Label.

**Keywords:** leakage; eye care; drug delivery; polymer

#### Introduction

Leakage and discolouration of Eye drops are very frequent and market complaint in USA market. In this Article I will try to explain these issues in three different steps like: Eye drop bottle and Cap design problems, Polymer compatibility problems with product and Leachable issues from Bottle Label.

#### Structure of the CAP:

- Position of the SPIKE should be at the center of the Cap that it exactly places on top of the Nozzle. Else first-time spike will pierce the nozzle but from next time on wards it will place outside the tip of the nozzle and product leakage observe.
- Height of the SPIKE is most important to avoid product Leakage.
- ➤ Rigidity of the SPIKE is most important.

#### Discolouration of Product observed

- After analyzing of the bottle polymer this has been observed quantity of the pigments are more compare to the standard.
- Excess pigments slowly leach with the product.
- After analyzing the polymer this has also been observed quantity of Additives are more and which was leached and mix with product and discoloration observed.

- Polymer Leachables are Polybutylene terephthalate (PBT) is a widely used polyester plastic in medical device and MDI valve components.
- PBT oligomers and other residuals or degradants can be similarly leached from the valve components fabricated from this material.

#### **Impact of Leachables in Drugs**

- Increased Toxicity
- ➤ Interfere Assay
- "Ph" change.

#### **Bottle Label**

Multiple inks, coating and adhesive are using during label printing.

- Printed Label Leachables are Phtoinitiators 1benzoylcyclohexanol and 2- hydroxyl-2-methylprophenone from ink used on labels of HDPE and glass bottles were found to migrate into a solid product.
- Adhesive Leachabels are Particulates Protein and Peptide Aggregation

Case Study: UV Curable Printing INK

Clinical Trials and Case Studies Page 2 of 4

For an extractables from a device component the AET  $(\mu g/g)$  can be determined

using Equation 1: Equation 1

 $AET = SCT.D_t$ 

 $D_{d}\,m$ 

D<sub>d</sub>- Doses per day

Dt- Total Labelled doses

m - mass of component

The AET ( $\mu g/device$ ) for a drug delivery device (e.g. an MDI) can be determined

from Equation 2:


 $AET = \underline{SCT. D_t}$ 

 $D_{d} \\$ 

D<sub>d</sub>- Doses per day


Dt- Total Labelled doses

#### Infrared Spectrum of a Heptane Extract of a Polycarbonate Component




TDS-GC/MS of polymeric material Photolysis of triaryl sulfonium salts


Clinical Trials and Case Studies Page 3 of 4



#### GC-MS Chromatogram of a Heptane Extract of a Polystyrene Component



Clinical Trials and Case Studies Page 4 of 4





#### **References:**

- Importance of Extractable and Leachable study for Primary Packaging Materials.
- 2. Role of packaging for NDDS (Neval drug delivery system) and NCE(Newchemicalentity)products.

Clinical Trials and Case Studies Page 5 of 4

#### Ready to submit your research? Choose ClinicSearch and benefit from:

- > fast, convenient online submission
- > rigorous peer review by experienced research in your field
- > rapid publication on acceptance
- authors retain copyrights
- > unique DOI for all articles
- immediate, unrestricted online access

#### At ClinicSearch, research is always in progress.

Learn more https://clinicsearchonline.org/journals/clinical-trials-and-case-studies



© The Author(s) 2025. **Open Access** This article is licensed under a Creative Commons Attribution 4.0 International License, which permits use, sharing, adaptation, distribution and reproduction in any medium or format, as long as you give appropriate credit to the original author(s) and the source, provide a link to the Creative Commons licence, and indicate if changes were made. The images or other third party material in this article are included in the article's Creative Commons licence, unless indicated otherwise in a credit line to the material. If material is not included in the article's Creative Commons licence and your intended use is not permitted by statutory regulation or exceeds the permitted use, you will need to obtain permission directly from the copyright holder. To view a copy of this licence, visit http://creativecommons.org/licenses/by/4.0/. The Creative Commons Public Domain Dedication waiver (http://creativecommons.org/publicdomain/zero/1.0/) applies to the data made available in this article, unless otherwise stated in a credit line to the data.